



Compatibility:

Heads - Malkoff E2HT, Malkoff E2XT, Malkoff EXIR 250/700, Surefire KM2C, Surefire KE2B, Modlite LED-T, Modlite LED-F.

Batteries - 2x CR123A

Tailcaps - Arisaka TC-2 Momentary, Surefire Z68, Surefire UE, Surefire DS

Mounts - All Arisaka mounts with "scout" in the name.

Assembly:

1. Insert CR123A cells into front of light body, positive ends toward the head.
2. Apply a small amount of dielectric grease to the threads on the light body.
3. Firmly thread on the head and tailcap. If using the TC-2 Momentary tailcap, back off 1/2 to 1 full turn for momentary operation.
4. Attach the light body to a compatible scout light mount. The light body to mount screws should be torqued to 20 inch lbs with loctite 222, 242, or 243.

Troubleshooting:

If the light will not turn on and the battery is known to be good and installed correctly, it is likely the tailcap is not screwed on tight enough or there's an issue with the tailcap/remote.

You can verify that the head/body/battery are working by removing the tailcap and using a conductive object like an Allen wrench or screwdriver to touch the rear of the battery and inner wall of the light body at the same time. If the light turns on then you know the problem lies with the tailcap or remote.

If you are using a remote switch and experience inconsistent switch behavior such as flickering, please contact the switch and/or tailcap manufacturer for help.