

Arisaka Hand Stop Picatinny Installation Guide
Patent Pending

02/01/2022

1. Insert a 7/64" Allen wrench into the hole on the bottom of the Hand Stop and engage the socket cap screw.
2. Turn the Allen wrench **clockwise** to draw the recoil lug fully into the Hand Stop.
3. Slide the Hand Stop onto the Picatinny rail to the desired position.
4. Line up the back of the Hand Stop with the edge of the picatinny slot (see arrow below)
5. Slowly turn the Allen wrench **counter-clockwise** to extend the recoil lug into the Picatinny rail.
6. It will take 5-6 full revolutions for the recoil lug to bottom out. Torque to no more than **15 inch lbs.**
7. If the recoil lug bottoms out after only 1-2 turns of the Allen wrench, then the Hand Stop must be repositioned according to step #4.

